



4). Screw the male connector to the female connector on the motor base. If it is not firmly, use a spanner.

